

GH 門禁系統

門外	遙控器		JD-700	116301	電鎖	
			CH-906	1161060	陽極/陰極鎖	
			CH904	116103	電鎖	
	感應機		CHJ-660S	1042701011	防拷 / 悠遊卡可通	
			CH-320	1042701021		
感應機配件		感應扣  104270201	感應卡  104270205	防潮盒  104270204		
門內	開關	押扣式 	BP41	104270304	大	
			BP21	104270306	小	
	感應式 	SI-25	1042703134	板/燈分開 10/12/15/18 : 為單顆開關,不含任何面板 20/22/25 : 為門框面板 60/62/65/68 : 為美規面板 80/82/85/88 : 為歐規面板		
鎖	電鎖 便當盒		鳥牌	正 烤漆	104220201	安裝圖/玻璃門配件 / 搭配LZ輔助支架104250105
				反	104220202	
			DD	正	104220203	
				反 ST	104220204	
			MH06	正	104220301	
				反 ST(雙)	104220302	
	磁力鎖 (斷電開)		CH600外露	104250102		
			CH600埋入	104260103	建議橫拉門用	
	陽極鎖 (公共用/斷電開)		ML230SLD	10423102		
			CH-200	104230104	方 / 八心	
			CH-200L	104230106	圓 / 八心	
			DA-15	104230108	外露式	
DA-64			104230113	內件遙控模組		
陰極鎖 (住宅用/通電開)		SHOWA EDM-103	104240110			
		CH-1505	104240205			
			104210101			
陰極鎖配件	斜舌腰鎖 	MIWA AST	104290530-306	心距 38. 51. 64mm / 單		
		MIWA AHS	104290601-633	心距 38. 51. 64mm / 雙		
		CH-738 .51	104170101	心距38mm / 單		
			104170201	心距51mm / 單		
			104170102	心距38mm / 雙		
104170202	心距51mm / 雙					
電磁扣 斷電開		DH-501	104280105	配合感應機 或 消防系統用		
		DH-502	104280108			
		DH-503	104280109			
		DH-504	104280107			
		DH-505	104280106			
隱藏式電鎖 斷電開		台製隱藏式電鎖 12005	104330190	金 / 單鎖心		
			104330191	白 / 單鎖心		
			104330193	金 / 雙鎖心		
		CISA 12015.50	104330116	金 / 雙面鎖心		
			104330117	金 / 單面鎖心		

備註：變壓器必備
護線管選配(外露/隱藏)